

Outdoor Speed Dome Camera Accessory



SD9368-EHL















SD9394-EHL




SD9384-EHL

*Wall Mount Bracket included with camera
(SD9368/84-EHL with AM-220; SD9394-EHL with AM-21P)

Mounting Type	Item	Number	Description	Image
 <p>Pendant Mount</p>	AM-114	1	Pendant Head (Outdoor)	
	AM-116	1	Pendant Pipe (20 cm) (1.5" PS11)	
	AM-117	1	Pendant Pipe (40 cm) (1.5" PS11)	
	AM-529	1	Mounting Adaptor	

Mounting Type	Item	Number	Description	Image
 <p>Wall / Pole/ Corner Mount</p>	AM-221	1	Gooseneck Bracket	
	AM-529	1	Mounting Adaptor	
	AM-718	1	Junction Box (Optional)	
	AM-314	Pole Mount Adapter		
	AM-315	Pole Mount Adapter		
	AM-414	Corner Mount Adapter		

* AM-314/ AM-315/ AM-414 Cannot be used together






Mounting Type	Item	Number	Description	Image
<p>Wall / Pole/ Corner Mount-1</p>	AM-220	1	Wall Mount Bracket	
	AM-718	1	Junction Box (Optional)	
	AM-314		Pole Mount Adapter	
	AM-315		Pole Mount Adapter	
	AM-414		Corner Mount Adapter	

* AM-314/ AM-315/ AM-414 Cannot be used together

Mounting Type	Item	Number	Description	Image
<p>Wall / Pole/ Corner Mount-2</p>	AM-21P	1	Wall Mount Bracket	
	AM-718	1	Junction Box (Optional)	
	AM-314		Pole Mount Adapter	
	AM-315		Pole Mount Adapter	
	AM-414		Corner Mount Adapter	

* AM-314/ AM-315/ AM-414 Cannot be used together



Mounting Type	Item	Number	Description	Image
 Parapet Mount	AM-231	1	Parapet Mounting Bracket	
	AM-529	1	Mounting Adaptor	